

Alinco DR-735T

Front Panel & Microphone Controls

Front panel	Mic	Press	Press & hold	FUNC then	FUNC +
SET	SET		Selects the Menu (p34)		
FUNC		M: shows freq (p 28)			
V/M	V/M	VFO / Memory	Switch to call channel (p 30)	Write to memory (p 23)	Erase the memory (p25)
				Skip and favorite ♥ (p 59)	
MW		Dual memory mode?	Easy memory writing (p 24)	MONI(p31) Reverse (p32)	Sets auto-dialer memory (p 67)
★		Programmable (p 63)		Change CTCSS DCS (p 65)	Sets RGB backlight color (p 63)
H/L O _{II}	H/L	Power level (p 33)	Locks keys (p 62)	Optional DVC (p 68)	Sets channel name (p 28)
Volume Knob		Switches MAIN (p 19)	Select Freq bands (p 19)	Overwrite memory (p 25)	Repeater shift & offset (p 22)
			Beep-Memory to VFO (p 26)		
MHz SCAN		VFO 1 MHz (p 21)	Scan (p 58)	Program scan (p 59)	Sets priority scan (p 61)
	MONI	Opens squelch (p 31)			
	MAIN	Switches MAIN (p 19)			
	BAND	Select Freq band (p 19)			
	CALL	Call channel (p 30)			
	Top	Change Channel	Scan (p 58)		

No functions

Normal use

Adding Memories

Using Memories

Erase or overwrite memories

Adding Memories (page 23)

In VFO mode select a freq and set parameters

FUNC

Dial to the memory #. Empty channels flash.

V/M to save it.

Add Alpha Tag (page 28)

In memory mode

FUNC + H/L

Rotate dial to select character

Press the dial knob to enter the next character

Repeat for each letter

Press any key to save the alpha tag